

OPTI-KLENS SYSTEMS

The dependable yet economical way to fulfill the requirement for an emergency eye or eye/face wash unit.

Everyone knows where the sink or basin is located. Even if temporarily blinded, they could find and operate the OPTI-KLENS unit.

The diverter pull button is designed to return to its original position automatically when the water is turned off. The sink is then always ready for everyday use.

The unit also has covers to protect nozzles from airborne contaminants, which are forced off when the unit is activated.

Check these features:

- Compact for easy shipping
- Sturdy, made of brass for long life
- Chrome finish to match fixtures

Try OPTI-KLENS, you'll see you've made the right choice!



All faucets can be purchased with the Eliminator valve. It will allow mixed faucets to be adjusted and set for a tempered water delivery from the Eye/Face Wash. This provides compliance with OSHA on the installation when there is a temperature requirement.

For use of the faucet, press the rod in one direction for water on, the other for off. The Eye/Face Wash is always available for emergency use no matter what position the Eliminator is in for sink use. Existing units can be converted by adding the Eliminator in place of the aerator on regular units.

DESERT ASSEMBLY, INC

653 Middlegate Road
Henderson, NV 89015

Phone: 702.565.5313
Fax: 702.565.7972
Email: www.desertassembly.com

DESERT ASSEMBLY, INC

OPTI-KLENS SYSTEMS

Our faucet mounted eyewash and eye/face wash fountains have been the leader in sales and innovation for over 20 years.

If you are familiar with faucet mounted products, it is likely your knowledge was acquired from seeing, buying or using an OPTI-KLENS product.

Compliance to ANSI Standard Z358.1, proven on all products through independent laboratory testing, accepted by OSHA to fulfill their requirements.

OPTI-KLENS I

OK-I mounts behind the faucet spout. It remains out of the way for everyday faucet use. However, the OK-I is always there as a permanent eyewash station when needed.

There is no plumbing required.
The OPTI-KLENS unit installs easily onto any faucet, in any sink, or basin.

Two of the most common adapters are packed with the unit.
If another adapter is needed, a free exchange is offered.

No professional installation required.



(Pictured with eliminator)

OPTI-KLENS II Regular

OK-II fills the need for a full Eye/Face wash. For use on *standard* faucets, delivering over 3 gallons of water per minute with softened flow heads.

For laboratory/gooseneck faucets use OK-II Lab.



(Pictured with eliminator)

OPTI-KLENS II Lab

OK-II Lab is for use on laboratory faucets, having a greater forward angle than OK-II Regular. With all the same features of the Regular, both units are stationary on faucet to reduce the risk of misalignment and non-compliance.



(Pictured with eliminator)

OPTI-KLENS IM

Wall mounted Eye/Face wash attach to 1/2" water line for plumbed installation

Stainless steel bowl

Priced less than plastic models!

Push paddle

Chrome plated brass pipe and ball valve

Cast aluminum bracket

Softened flow heads with dust covers



DESERT ASSEMBLY, INC

653 Middlegate Road
Henderson, NV 89015

Phone: 702.565.5313
Fax: 702.565.7972
Email: www.desertassembly.com